# Hidden Soldier Detection

양지현 김근호 김미라 오석준 권형근 우유정



# Content

- 1. Data
- 2. Model
- 3. Experiment
- 4. Test



# 1. Data

### %Object





# 1. Data — filtering(2000)

#### X Desirable



- 목표 적합성
- 'Person' 특성 최소화
- 학습 용이성

#### **X** Undesirable



- 지형지물 이용 정도가 큼
- 육안 식별의 어려움
- 성능 저하



# 1. Data — Preprocessing 1.

### ※ Resizing

- 416\*416 for YOLO V3 input
- 정보손실 최소화

### **X** Renaming

```
# 코램에서
from google.colab.patches import cv2 imshow
import os
import cv2
# 이미지들 넣은 경로
path = '/content/gdrive/My Drive/Colab Notebooks/keras-volo3/고니/'
# 파일 불러오기
file list = os.listdir(path)
file list ipg = [file for file in file list if file.endswith('.ipg')]
W = 416
H = 416
new path = '/content/gdrive/My Drive/Colab Notebooks/keras-yolo3/ユ니/resized/'
# for문으로 이미지 돌리기
for idx in range(len(file_list_jpg)):
 img_jpg = file_list_jpg[idx]
  img_path = path + img_jpg
  img = cv2.imread(img path)
  img = cv2.resize(img, (W, H), interpolation = cv2.INTER_AREA)
 cv2.imwrite(str(new_path) + str(idx) + '.jpg', img)
```



# 1. Data — Preprocessing 2.


#### Labelme

- **X Direct to JSON**
- **X** Segmentation
- ※ Polygons or Circle etc..

We defined

Soldier, group id =0 Gun, group id=1

#### 사용 예시





# 1. Data — Preprocessing 3.

```
309.59829059829065.
116.00854700854703.
407.2649572649573
204.8974358974359
205.12820512820514
127.974358974359.
413.6752136752137
```

← JSON data format

Input data format for YOLO V3

path/to/img2.jpg 120,300,250,600,2

Training

1. Generate your own annotation file and class names file. One row for one image: Row format: image file path box1 box2 ... boxN; Box format: x min, y min, x max, y max, class id (no space). For VOC dataset, try python voc annotation.py Here is an example: path/to/img1.jpg 50,100,150,200,0 30,50,200,120,3

```
import os
import ison
# ison파일들 있는 폴더
file path = '/content/labeling/'
# 라벨링된 이미지 이름들
file list = os.listdir(file path)
file list ison = [file for file in file list if file.endswith('.ison')]
print(file list ison)
# 파일 리스트 이를 수으로 제정렬
print(len(file_list_json))
def get sol dicts(img dir):
  # 전체 ison data 들어갈 리스트
  dataset_dicts = []
  # 라벨링된 이미지 리스트에서 가져오기
 for idx in range(len(file_list_json)):
   file_name = file_list_ison[idx] # '447./son'
json_path = '/content/labeling/' + file_list_json[idx]
height, width = (416, 416)
   file_name = file_name[:-4] + 'ipg'
    # print(file name)
   record['image_id'] = idx
record['height'] = height
record['width'] = width
   obis - []
    with open(json_path) as f:
     json_data = json.load(f)
    for i in range(len(json_data['shapes'])):
         "bbox': json_data['shapes'][i]['points'][0] + json_data['shapes'][i]['points'][i],
"bbox_mode": BoxMode.XYXY_ABS,
          'category_id': 0 if json_data['shapes'][0]['label'] -- 'soldiers' else 1,
          "iscrowd": 0
     obis.append(obi)
    record['annotations'] - objs
    dataset_dicts.append(record)
    return dataset_dicts
# print('=======finish/======
```




# 2. Model



### 2.1 Mask R-CNN

#### **X Mask R-CNN**

#### **Mask R-CNN**




- Object Detection & Image Segmentation
- High AP (Average Precision)
- X Disadvantage
- Labelling
- Time
- **X** Conclusion
- 적절하지 않다



# 2.2 EfficientDet

#### **X** EfficientDet

#### MS COCO Object Detection




- BiFPN 구조 고안
- High AP (Average Precision)
- X Disadvantage
- Code를 찾기 어려움
- Time
- **X** Conclusion
- 적절하지 않다




### 2.3 YOLO v3

#### **XYOLO v3**




- 매우 빠른 속도 (Regression problem)
- Image의 전역 파악 (Contextual information)
- Generalizable representation 학습
- **X** Disadvantage
- 높은 localization error
- **X** Conclusion
- 적절하다





#### **X** RetinaNet



- 빠른 속도 (One-stage)
- High AP
- Focal Loss
- **X** Disadvantage
- YOLO에 비해 느린 속도
- **X** Conclusion
- 적절하다



# 3.Experiment



### 3.1 YOLO v3

#### **X** Training

```
# Adjust num epochs to your dataset. This step is enough to obtain a not bad model
                                                                                                                                def main():
                                                                                                                                    annotation_path = 'train.txt'
    model.compile(optimizer=Adam(lr=1e-3). loss={
                                                                                                                                   log dir = 'logs/000/'
       # use custom volo loss Lambda laver.
                                                                                                                                   classes path = 'model data/voc classes.txt'
        'volo loss': lambda v true, v pred: v pred})
                                                                                                                                    anchors path = 'model data/volo anchors.txt'
                                                                                                                                   class_names = get_classes(classes_path)
   batch size = 32
                                                                                                                                   num classes = len(class names)
   print('Train on {} samples, val on {} samples, with batch size {},'.format(num train, num val, batch size))
                                                                                                                                    anchors = get anchors(anchors path)
   model.fit generator(data generator wrapper(lines[:num train], batch size, input shape, anchors, num classes).
           steps_per_epoch=max(1, num_train//batch_size).
                                                                                                                                    input shape = (416,416) # multiple of 32, hw
           validation_data=data_generator_wrapper(lines[num_train:], batch_size, input_shape, anchors, num_classes),
           validation steps=max(1, num val//batch size).
                                                                                                                                   is_tiny_version = len(anchors)==6 # default setting
           epochs=50.
                                                                                                                                    if is tiny version:
            initial_epoch=0.
                                                                                                                                        model = create tiny model(input shape, anchors, num classes,
           callbacks=[logging, checkpoint])
                                                                                                                                            freeze body=2, weights path='model data/tiny volo weights.h5')
   model.save weights(log dir + 'trained weights stage 1.h5')
                                                                                                                                    else:
                                                                                                                                        model = create_model(input_shape, anchors, num_classes,
# Unfreeze and continue training, to fine-tune.
                                                                                                                                            freeze body=2, weights path='model data/volo weights.h5') # make sure you know what you freeze
# Train longer if the result is not good.
if True
                                                                                                                                    logging = TensorBoard(log_dir=log_dir)
    for i in range(len(model.layers)):
                                                                                                                                    checkpoint = ModelCheckpoint(log_dir + 'ep{epoch:03d}-loss{loss:.3f}-val_loss{val_loss:.3f}.h5',
        model.layers[i].trainable = True
                                                                                                                                        monitor='val_loss', save_weights_only=True, save_best_only=True, period=3)
    model.compile(optimizer=Adam(Ir=1e-4), loss={'yolo_loss': lambda y_true, y_pred: y_pred}) # recompile to apply the change
                                                                                                                                   reduce_Ir = ReduceLROnPlateau(monitor='val_loss', factor=0.1, patience=3, verbose=1)
   print('Unfreeze all of the layers.')
                                                                                                                                    early_stopping = EarlyStopping(monitor='val_loss', min_delta=0, patience=10, verbose=1)
   batch_size = 32 # note that more GPU memory is required after unfreezing the body
                                                                                                                                    val_split = 0.1
   print('Train on {} samples, val on {} samples, with batch size {},',format(num train, num val, batch size))
                                                                                                                                    with open(annotation path.encoding='cp949') as f:
   model.fit_generator(data_generator_wrapper(lines[:num_train], batch_size, input_shape, anchors, num_classes),
                                                                                                                                        lines = f.readlines()
       steps_per_epoch=max(1, num_train//batch_size).
                                                                                                                                   np.random.seed(10101)
       validation data=data generator wrapper(lines[num train:], batch size, input shape, anchors, num classes).
                                                                                                                                   np.random.shuffle(lines)
```

### 3.1 YOLO v3

 $curr_fps = curr_fps + 1$ 

#### X Detecting image

```
while True:
def detect video(volo, video path, output path=""):
    import cv2
                                                                                                                                    return value, frame = vid.read()
   vid = cv2.VideoCapture(video path)
                                                                                                                                    image = Image.fromarray(frame)
   if not vid.isOpened():
                                                                                                                                    image = yolo.detect_image(image)
        raise INError("Couldn't open webcam or video")
                                                                                                                                    result = np.asarrav(image)
   video_FourCC = int(vid.get(cv2.CAP_PROP_FOURCC))
                                                                                                                                    curr time = timer()
   video fps
                   = vid.get(cv2.CAP PROP FPS)
                                                                                                                                    exec_time = curr_time - prev_time
   video_size
                   = (int(vid.get(cv2.CAP_PROP_FRAME_WIDTH)).
                                                                                                                                    prev_time = curr_time
                        int(vid.get(cv2.CAP_PROP_FRAME_HEIGHT)))
                                                                                                                                    accum_time = accum_time + exec_time
    isOutput = True if output_path != "" else False
                                                                                                                                    curr_fps = curr_fps + 1
   if isOutput:
                                                                                                                                    if accum time > 1:
        print("!!! TYPE:", type(output_path), type(video_FourCC), type(video_fps), type(video_size))
                                                                                                                                        accum_time = accum_time - 1
        out = cv2. VideoWriter(output path. video FourCC, video fps. video size)
                                                                                                                                        fps = "FPS: " + str(curr_fps)
   accum time = 0
                                                                                                                                        curr_fps = 0
   curr_fps = 0
                                                                                                                                    cv2.putText(result, text=fps, org=(3, 15), fontFace=cv2.FONT_HERSHEY_SIMPLEX,
   fps = "FPS: ??"
                                                                                                                                                fontScale=0.50, color=(255, 0, 0), thickness=2)
    prev_time = timer()
   #fig = plt.figure()
                                                                                                                                    cv2_imshow(result)
    while True:
                                                                                                                                    if isOutput:
                                                                                                                                        out.write(result)
        return_value. frame = vid.read()
                                                                                                                                    if cv2.waitKey(1) & 0xFF == ord('g'):
        image = Image.fromarray(frame)
                                                                                                                                       break
                                                                                                                                yolo.close_session()
        image = volo.detect image(image)
        result = np.asarray(image)
        curr_time = timer()
        exec time = curr time - prev time
        prev_time = curr_time
        accum_time = accum_time + exec_time
```

### 3.1 YOLO v3

#### X Detecting video

```
python_yolo_video.py --input /content/sample_data/soldier.mp4 --output /content/sample_data
    person 1.00 (410, 40) (595, 436)
    3.5859358379993864
    <PIL.Image.Image image mode=RGB size=854×480 at 0×7FFA64A99208>
    (416, 416, 3)
    Found 7 boxes for ima
    person 0.34 (612, 48) (675, 148)
    person 0.78 (763, 0) (854, 392)
    person 0.95 (83, 40) (203, 466)
    person 0.97 (603, 6) (802, 385)
    person 0.99 (140, 16) (319, 480)
    person 1.00 (279, 48) (422, 480)
    person 1.00 (411, 40) (595, 432)
    3.6446833469999547
    <PIL.Image.Image image mode=RGB size=854x480 at 0x7FFA64AD8C50>
    (416, 416, 3)
    Found 7 boxes for img
    person 0.37 (611, 39) (673, 148)
    person 0.74 (765, 0) (854, 387)
    person 0.87 (83, 38) (202, 467)
    person 0.97 (600, 4) (797, 388)
    person 0.99 (136, 15) (320, 480)
    person 1.00 (278, 36) (427, 480)
    person 1.00 (414, 42) (597, 417)
    3.621995275999325
    <PIL.Image.Image image mode=RGB size=854×480 at 0×7FFA64A487B8>
```

#### ※ 요구 형식에 맞게 파일 구조 정리

```
record['file name'] = file name
record['image id'] = idx
record['height'] = height
record['width'] = width
objs = []
with open(ison path) as f:
 json data = json.load(f)
for i in range(len(json data['shapes'])):
 obj = {
      'bbox' : json data['shapes'][i]['points'][0] + json data['shapes'][i]['points'][1],
     "bbox mode": BoxMode.XYXY ABS,
     'category id': 0 if json data['shapes'][0]['label'] == 'soldiers' else 1,
     # if json data['shapes'][0]['label'] == 'soldiers':
     # "category id": 0
     # elif json data['shapes'][0]['label'] == 'gun':
     # "category id": 1
     "iscrowd": 0
 objs.append(obj)
record['annotations'] = objs
dataset dicts.append(record)
return dataset dicts
```

```
[5] # json파일들 있는 폴더
    file path = '/content/labeling/'
    # 라벨링된 이미지 이름들
    file list = os.listdir(file path)
    file list json = [file for file in file list if file.endswith('.json')]
    print(file list json)
    # 파일 리스트 이름 순으로 재정렬
    print(len(file list json))
    def get sol dicts(img dir):
      # 전체 json data 들어갈 리스트
      dataset dicts = []
      # 라벨링된 이미지 리스트에서 가져오기
      for idx in range(len(file_list_json)):
        record = {}
        file name = file list json[idx] # '447.json'
        json_path = '/content/labeling/' + file_list_json[idx]
        height, width = (416, 416)
        file name = file name[:-4] + 'jpg'
        # print(file name)
```



#### **X** Training

```
[8] from detectron2.engine import DefaultTrainer
    from detectron2.config import get cfg
    cfg = get cfg()
    cfq.merge from file("/content/detectron2 repo/confiqs/COCO-Detection/retinanet R 50 FPN 3x.yaml")
    cfg.DATASETS.TRAIN = ("balloon train",)
    cfg.DATASETS.TEST = ()
    cfg.DATALOADER.NUM WORKERS = 2
    cfg.MODEL.WEIGHTS = "detectron2://COCO-Detection/retinanet R 50 FPN 3x/137849486/model final 4cafe0.pk;
    cfg.SOLVER.IMS PER BATCH = 2
    cfg.SOLVER.BASE LR = 0.00025
    cfg.SOLVER.MAX ITER = 300
    cfg.MODEL.ROI HEADS.BATCH SIZE PER IMAGE = 128
    cfg.MODEL.ROI HEADS.NUM CLASSES = 2 # 클래스는 soldier, gun 2개
    os.makedirs(cfg.OUTPUT DIR, exist ok=True)
    trainer = DefaultTrainer(cfg)
    trainer.resume or load(resume=False)
    trainer.train()
            (3): BottleneckBlock(
              (conv1): Conv2d(
                1024, 256, kernel size=(1, 1), stride=(1, 1), bias=False
                (norm): FrozenBatchNorm2d(num_features=256, eps=1e-05)
              (conv2): Conv2d(
                256, 256, kernel size=(3, 3), stride=(1, 1), padding=(1, 1), bias=False
                (norm): FrozenBatchNorm2d(num_features=256, eps=1e-05)
```



※ Test 과정

```
cfg = get_cfg()
# 각 테스크에 맞는 적절한 config을 추가
cfg.merge_from_file("/content/detectron2_repo/configs/COCO-Detection/retinanet_R_50_FPN_3x.yaml")
cfg.MODEL.RETINANET.SCORE_THRESH_TEST = 0.5 # set threshold for this model


cfg.MODEL.WEIGHTS = "detectron2://COCO-Detection/retinanet_R_50_FPN_3x/137849486/model_final_4cafe0.pkl"
predictor = DefaultPredictor(cfg)
outputs = predictor(im)

[. Loading config /content/detectron2_repo/configs/COCO-Detection/../Base-RetinaNet.yaml with yaml.unsafe_load.
```





※ Test 결과







※ 동영상 Test 결과





# 3.Result





- 고된 수작업 라벨링 과정에서 발생한 동기애
- 다양한 모델에 대해 연구
- Transfer learning 에 대한 이해
- Gpu의 필요성... 코랩의 한계점 파악....



#### 한계점

- Person과 soldier를 구분하지 못함 → COCO dataset으로 pre trained 된 모델을 transfer learning 하다 보니, COCO에서 person으로 많은 학습이 이루어짐
- 종속관계를 파악하지 못함 (person >> soldier)
- Person으로 학습이 이루어지지 않은 weight를 불러오면 해결 될 것이라 생각함



# 감사합니다!

